

(2) Position and weld side plates after corner plates.

Table 4

Required Parts for the Installation of 242-3145 Rubber Body Liner Gp for the 242-3170 Dual Slope Body for the 777F and 777G Truck (If Equipped)		
Qty	Part Number	Description
1	269-8517 ⁽¹⁾ ✓	Rubber Liner Assembly
1	269-8518 ⁽¹⁾ ✓	Rubber Liner Assembly
1	269-8519 ⁽¹⁾ ✓	Rubber Liner Assembly
1	269-8520 ⁽¹⁾ ✓	Rubber Liner Assembly
1	269-8521 ⁽¹⁾ ✓	Rubber Liner Assembly
1	269-8522 ⁽¹⁾ ✓	Rubber Liner Assembly
1	269-8523 ⁽¹⁾ ✓	Rubber Liner Assembly
1	269-8524 ⁽¹⁾ ✓	Rubber Liner Assembly
1	269-8525 ⁽¹⁾ ✓	Rubber Liner Assembly

https://sis.cal.com/sisweb/sisweb/techdoc/techdoc_print_page.jsp?returnurl=/sisweb/sisweb/mediasearch/mediasearchinfoframeset_sp&calledpage=... 4/84

6/12/2018

By NPR - REHS2653 - Assembly Procedure for the Dual Slope Body for the 777F and 777G Off-Highway Truck(7258, 7960)

1	269-8526 ⁽¹⁾ ✓	Rubber Liner Assembly
1	270-0368	Tail Bar Plate Assembly
1	270-0369	Tail Bar Plate Assembly
1	270-0370	Tail Bar Plate Assembly
128	308-6689	Weld Stud
128	274-1338	Rubber Plug
128	2J-3506	Full Nut
128	7X-0564	Hard Washer
2	305-3438 ⁽¹⁾	Plate
2	129-0391	Plate
2	129-0392	Plate
2	129-0400	Plate
2	129-0393	Plate
2	129-0395	Plate
2	129-0397 ⁽²⁾	Plate
2	129-0387	Plate
2	129-0386 ⁽²⁾	Plate
4	297-2802	Plate
2	297-2803	Plate

(1) Place rubber liners and plate assemblies in truck body to locate weld studs.

(2) Plate to installed after finish welding body and canopy.